



## Instructions for Use Sealing Kit



# Instructions for Use Qboard® Sealing Kit

## Fields of application

For sealing the joints on Qboard® basiq construction boards and/or Qboard® liquid shower elements when combined with ceramic tiles in wet rooms, showers and the like.

## Application

Before use, please read the safety recommendations on the tub label. Application temperature: +5°C to +20°C

Mix both components in a clean container until you have a homogeneous consistency that is free of lumps and suitable for application. The two components are supplied in the correct proportions. Using a firm brush or palette knife, apply the product thickly to the surface of all butt joints of Qboard® basiq construction boards and/or Qboard® liquid shower elements that require sealing. Try to avoid layers of more than 1.5 mm thickness. Apply the sealant over the width of the sealing tape + 1 cm overlap.

The sealant is sufficient for around 10 m. Use mixed material within half an hour.

Do not add water or liquid component to try and revive sealant that has already started to harden.

Start in the corners by embedding the sealing corners smoothly into the sealant. Then cover the top surface of the sealing corners with sealant before positioning the sealing tape centrally over the joints to be sealed and fixing it in place smoothly and without creases. When positioning the sealing tape on the sealing corners, allow a butt joint overlap of around 50 mm.

Then apply a second layer of sealant to the sealing tape. After 4 hours, ceramic tiles can be fixed on the sealant using thin bed of tile adhesive.

## Please note:

The information provided in this leaflet is based on our knowledge and experience to date. It does not constitute a guarantee in any legal sense. When using this product, please always bear in mind the circumstances of the particular intended application, especially with regard to physical, technical and legal construction issues.