




## Installation Instructions


**Qboard®** basi**q** **reno**

For any painting and tiling applications


# Installation Instructions Qboard® basiq reno




The subsurface must be clean (free from remnants of paint and adhesive, etc.) and dust-free.




Qboard® basiq reno can be plastered, painted, wallpapered or tiled afterwards.




Cut the board to size with a knife or hand saw.



Apply a type flexible tile adhesive to the entire surface and fix to a level substrate (align if necessary).



Qboard® basiq reno must be fixed evenly and flush to the wall. Subsequent adjustments can be made with slight pressure on the board.



Glass-fibre tape or joint tape must be applied to all butt joints which should then be covered with two thin layers of filler.

## General notes on using paint and tiles

### Paint:

To prevent the paint from drying out too quickly and cracking, a deep primer must first be applied or a non-woven scrim used.

### Wallpaper:

When using wallpaper, a wallpaper primer or a non-woven scrim must first be applied. To achieve a perfect finish, it is recommended to paint the surface with white paint before wallpapering.

### Filling techniques:

Generally, the same or a harder grade of filler is used in the butt joint than for the full-surface skim coating, to ensure flexibility. For optimum adhesion, fillers (dispersion or gypsum filler, 2-3 mm thick) require priming with a quartz primer. Alternatively, you can use a non-woven scrim for filler work. If the skim coating is < 2 mm, a scrim must be used for filler work.

### Tiles:

Use flexible cement based adhesives as a tile adhesive.

The instructions from the manufacturers of the adhesives, fillers, wallpapers and paints must be followed during your work.

**Please note:** The information provided in these installation instructions is based on our knowledge to date and reflects best engineering practice. It does not constitute a guarantee in any legal sense or a contractual obligation. When using this product, please always bear in mind the circumstances of the particular intended application, especially with regard to physical, technical and legal construction issues, in order to adapt the information contained in these installation instructions accordingly and to ensure installation in line with best engineering practice.

Qboard® is a registered trademark of Jackon Insulation GmbH – errors and modifications excepted.  
JACKON Insulation GmbH • Carl-Benz-Straße 8 • D-33803 Steinhagen, Germany • Telephone +49 5204 9955-320 • Fax +49 5204 9955-300  
info@myqboard.com • [www.myqboard.com](http://www.myqboard.com)